





8933

TABLET HOLDER WALL




- DE Gebrauchsanleitung
- GB Instruction Manual
- FR Notice d'emploi
- NL Instructies
- ES Manual de instrucciones
- IT Istruzioni d'uso
- SE Bruksanvisning
- PL Instrukcją obsługi
- RU Руководство по эксплуатации













360°







3 | TABLET HOLDER WALL




























DURABLE

DURABLE · Hunke & Jochheim GmbH & Co. KG

Westfalenstraße 77-79 · 58636 Iserlohn

P.O. Box 1753 · 58634 Iserlohn · Germany

Phone ++49-2371-662-0 · Fax ++49-2371-662-221

durable@durable.de · www.durable.eu